#### Updated: Monday, September 4, 17

I did not look for a long time to this article, until I recently got a request to help another radio ham.

Obviously, the old script and commands no longer work. And since there was a new Raspberry PI available, as well as a cheap 7inch tablet, I decided to give it a try over the week-end.

This document now describes the both the installation of the basic Dantracker from Dan Smith as well as the extended version by Basil, N7NIX. I have checked the latter, and may do so later also to Dan's basic version.

For N7NIX version, there will be a fully automatic installation script for the Raspian Stretch distro available on my website later on.

#### **AUTO INSTALLATION**



Login <u>as root</u> to your RPI, change into the /home/pi directory (create if you don't have it) and execute the following:

Install some prerequisite packages

sudo apt-get install build-essential libx11-dev zlib1g-dev libncurses5dev autoconf autogen libtool sudo libgps-dev bridge-utils git-core libnl-3-dev

libnl-genl-3-dev libjson0 libjson0-dev nodejs screen git python-serial libgtk2.0-dev gtk+-2.0 gcc pkg-config imagemagick automake autoconf libtool cvs curl libncurses-dev libssl-dev locate dnsmasq rfkill

next install the auto install script:

wget <u>http://www.pa0esh.com/svn/install\_dantracker.sh</u>

Then execute

chmod +x install\_dantracker.sh && ./install\_dantracker.sh

Here you see my "test" station: Raspberry PI – 4 port powered hub with WiPi, GPS mouse and flash-disk for OS connected, TNC-X connected to the old Icom IC200H. I had a small LCD screen to go along in case I used the original Dantracker (co-installed). However, the screen died on me and I only use the N7NIX version.

This should have worked and after you restart, the dantracker should be working. If not follow the individual steps below and see where the installations crashes. From there on it is most of the time possible to detect the reason for the crash and to solve it.

### FRESH INSTALLATION FOR RASPBERRY PI MOD II – RASPIAN STRETCH

Take (minimal) a <u>8Gb</u> sd disk of good quality..... Install Raspbian Stretch (either version) as per Raspberry PI Download -<u>http://www.raspberrypi.org/downloads/</u> I advice for Mac and Windows users <u>https://etcher.io/#downloads</u> to put the Raspbian image on an SD card.

Or check the site https://www.raspberrypi.org/downloads/raspbian/ and follow the instructions.

Now start your Raspberry. If you use a display attached to your Raspberry PI, follow the onscreen instructions and finish off.

If you use ssh, find the address of the raspberry (I use LanScan) and ssh into it (ssh pi@x.x.x.x). Please note that a virgin image does not have ssh enabled. So you must first use an attached screen en keyboard.

Make sure to change the PI password.... And create also a root password. Then reboot

Log-in as user pi

#### ssh pi@x.x.x.x -X (x.x.x.x is the ip address of my RPI)

If you go for the Dantracker N7NIX version, you do need the Raspberry to convert into an Access Point in your car, unless you have already an access point up and running inside..... Using an iPhone hotspot utility, is one option, but not stable (so far for me) Here is a solution to install **hostapd** with supporting **dhcp** en masquerading tools – **dnsmasq**.

You need internet access for this step so make sure that Ethernet connection is up!

#### **SETUP THE PRE REQUISITES**

To compile Dantracker and install supporting software, we are first installing all prerequisite packes.

sudo apt-get install build-essential libx11-dev zlib1g-dev libncurses5-dev autoconf autogen libtool sudo libgps-dev bridge-utils git-core libnl-3-dev libnl-genl-3-dev libjson0 libjson0-dev nodejs screen git python-serial libgtk2.0-dev gtk+-2.0 gcc pkg-config imagemagick automake autoconf libtool cvs curl libncurses-dev libssl-dev locate dnsmasq rfkill

Note: since this document was written in 2015, some software has been updated and you may have to install a newer version. In that case the software will not install at all, and indicate to you which part is not working.

#### INSTALL HOSTAPD & DNSMASQ

#### PACKAGES

The first step is to install the required packages: sudo apt-get install dnsmasg hostapd I'll go into a little detail about the two:

**hostapd** - This is the package that allows you to use the built in WiFi as an access point **dnsmasq** - This is a combined DHCP and DNS server that's very easy to configure If you want something a little more 'heavyweight', you can use the isc-dhcp-server and bind9 packages for DHCP and DNS respectively, but for our purposes, dnsmasq works just fine.

#### **CONFIGURE YOUR INTERFACES**

The first thing you'll need to do is to configure your wlan0 interface with a static IP. If you're connected to the Pi via WiFi, connect via Ethernet / serial / keyboard first.

In newer Raspian versions, interface configuration is handled by dhcpcd by default. We need to tell it to ignore wlan0, as we will be configuring it with a static IP address elsewhere. So open up the dhcpcd configuration file with

sudo nano /etc/dhcpcd.conf

and add the following line to the bottom of the file:

denyinterfaces wlan0

Note: This must be ABOVE any interface lines you may have added!

Now we need to configure our static IP. To do this open up the interface configuration file with sudo nano /etc/network/interfaces and edit the wlan0 section so that it looks like this:

allow-hotplug wlan0 iface wlan0 inet static address 172.24.1.1 netmask 255.255.255.0 network 172.24.1.0 broadcast 172.24.1.255 # wpa-conf /etc/wpa supplicant/wpa\_supplicant.conf

Restart dhcpcd with sudo service dhcpcd restart and then reload the configuration for wlan0 with

sudo ifdown wlan0; sudo ifup wlan0.

#### **CONFIGURE HOSTAPD**

Next, we need to configure hostapd. Create a new configuration file with sudo nano /etc/hostapd/hostapd.conf with the following contents:

```
# This is the name of the WiFi interface we configured above
interface=wlan0
# Use the nl80211 driver with the brcmfmac driver
driver=nl80211
# This is the name of the network
ssid=Pi3-AP
# Use the 2.4GHz band
hw mode=g
```

```
# Use channel 6
channel=6
# Enable 802.11n
ieee80211n=1
# Enable WMM
wmm enabled=1
# Enable 40MHz channels with 20ns guard interval
ht capab=[HT40][SHORT-GI-20][DSSS CCK-40]
# Accept all MAC addresses
macaddr acl=0
# Use WPA authentication
auth algs=1
# Require clients to know the network name
ignore broadcast ssid=0
# Use WPA2
wpa=2
# Use a pre-shared key
wpa key mgmt=WPA-PSK
# The network passphrase
wpa passphrase=raspberry
# Use AES, instead of TKIP
rsn pairwise=CCMP
```

We can check if it's working at this stage by running sudo /usr/sbin/hostapd /etc/hostapd/hostapd.conf. If it's all gone well thus far, you should be able to see to the network Pi3-AP! If you try connecting to it, you will see some output from the Pi, but you won't receive and IP address until we set up dnsmasq in the next step. Use Ctrl+C to stop it.

Note: with an old WiFi adapter you may have to delete the WMM lines. (I did require that with an early WiPi interface)

We aren't quite done yet, because we also need to tell hostapd where to look for the config file when it starts up on boot. Open up the default configuration file with

sudo nano /etc/default/hostapd

```
and find the line #DAEMON_CONF="" and replace it with DAEMON_CONF="/etc/hostapd/hostapd.conf".
```

#### **CONFIGURE DNSMASQ**

The shipped dnsmasq config file contains a wealth of information on how to use it, but the majority of it is largely redundant for our purposes. I'd advise moving it (rather than deleting it), and creating a new one with

sudo mv /etc/dnsmasq.conf /etc/dnsmasq.conf.orig

🔸 🔰 sudo nano /etc/dnsmasq.conf

Paste the following into the new file:

```
interface=wlan0  # Use interface wlan0
listen-address=172.24.1.1 # Explicitly specify the address to listen on
bind-interfaces  # Bind to the interface to make sure we aren't sending
things elsewhere
server=8.8.8.8 # Forward DNS requests to Google DNS
```

domain-needed # Don't forward short names bogus-priv # Never forward addresses in the non-routed address spaces. dhcp-range=172.24.1.50,172.24.1.150,12h # Assign IP addresses between 172.24.1.50 and 172.24.1.150 with a 12 hour lease time

#### **SET UP IPV4 FORWARDING**

One of the last things that we need to do before we send traffic anywhere is to enable packet forwarding.

To do this, open up the sysctl.conf file with

sudo nano /etc/sysctl.conf

and remove the # from the beginning of the line containing net.ipv4.ip\_forward=1. This will enable it on the next reboot, but because we are impatient, activate it immediately with :

sudo sh -c "echo 1 > /proc/sys/net/ipv4/ip\_forward"

We also need to share our Pi's internet connection to our devices connected over WiFi by the configuring a NAT between our wlan0 interface and our eth0 interface. We can do this using the following commands:

- sudo iptables -t nat -A POSTROUTING -o eth0 -j MASQUERADE
- sudo iptables -A FORWARD -i eth0 -o wlan0 -m state --state RELATED,ESTABLISHED
   -j ACCEPT
- sudo iptables A FORWARD i wlan0 o eth0 j ACCEPT

However, we need these rules to be applied every time we reboot the Pi, so run

sudo sh -c "iptables-save > /etc/iptables.ipv4.nat"

to save the rules to the file /etc/iptables.ipv4.nat. Now we need to run this after each reboot, so open the rc.local file with

sudo nano /etc/rc.local

and just above the line **exit 0**, add the following line:

iptables-restore < /etc/iptables.ipv4.nat</pre>

#### WE'RE ALMOST THERE!

Now we just need to start our services:

- sudo service hostapd start
- sudo service dnsmasq start

And that's it! You should now be able to connect to the internet through your Pi, via the onboard WiFi!

To double check we have got everything configured correctly, reboot with \$\overline\$ sudo reboot.

#### SET UP WLANO FOR STATIC IP

If you happen to have wlan0 active because you set it up, run sudo ifdown wlan0 There's no harm in running it if you're not sure. Never mind the warning. Next we will set up the wlan0 connection to be static and incoming. Run sudo nano /etc/network/interfaces to edit the file

Find the line auto wlan0 and **add a # in front of the line**, and in front of every line afterwards. Depending on your existing setup/distribution there might be more or less text and it may vary a little bit

Add the lines:

iface wlan0 inet static address 192.168.42.1 netmask 255.255.255.0

#### After allow hotplug wlan0

Save the file

Assign a static IP address to the Wi-Fi adapter by running

apt-get install rfkill

sudo ifconfig wlan0 192.168.42.1

Now make sure that it does not lose this static ip number during startup. Check that is installed

#### apt-get install ifplugd

In /etc/default/ifplugd, the default configuration is normally the following:

```
INTERFACES="auto"
HOTPLUG_INTERFACES="all"
ARGS="-q -f -u0 -d10 -w -I"
SUSPEND_ACTION="stop"
```

Simply change it to this (even if the file looked different as above):

```
INTERFACES="eth0"
HOTPLUG_INTERFACES="eth0"
ARGS="-q -f -u0 -d10 -w -I"
SUSPEND ACTION="stop"
```

This will ensure that wlan0 will not lose it's static IP address that's configured in /etc/network/interfaces when wlan0 goes up.

Now reboot the Raspberry PI and check if you can access the Wi-Fi and that you have internet connectivity available.

#### CONTINUE WITH INSTALLING DANTRACKER

Download either the original dantracker source

- \rm 🖌 cd /home/pi
- git clone <u>https://github.com/kk7ds/dantracker</u>

#### or the N7NIX branch

- git clone <u>https://github.com/n7nix/dantracker</u>
- 🔸 🛛 cd dantracker

Download and install libfab

- sudo wget http://pakettiradio.net/downloads/libfap/1.5/libfap-1.5.tar.gz
- tar xvzf libfap-1.5.tar.gz
- sudo cp libfap-1.5/src/fap.h /usr/local/include/
- d libfap-1.5

Now apply the fap patch:

patch -p2 < /<path\_to\_tracker\_src>/fap\_patch.n7nix

To find the path to the dantracker source, type *pwd*. Since you are in the libfap-1.5 directory (you should be !), the *path\_to\_tracker\_src* is what is shown with pwd, less libfap-15.

Example: pwd -> /home/pi/dantracker/libfap-1.5, then the patch command is **patch -p2 < /home/pi/dantracker/fap\_patch.n7nix** 

- sudo cp src/fap.h /usr/local/include/
- 4. ./configure
- make && sudo make install
- cd .. (go back to the dantracker directory)

Install iniparser - http://ndevilla.free.fr/iniparser/

- git clone http://github.com/ndevilla/iniparser.git
- \rm 🚽 cd iniparser
- cp src/iniparser.h /usr/local/include
- cp src/dictionary.h /usr/local/include
- make
- cp libiniparser.\* /usr/local/lib
- Idconfig
- d .. (back to the standard dantracker directory)

Note – The next part applies to the N7NIX branch only

#### ====== BOF N7NIX INSTALLATION RASPBERRY PI – DEBIAN JESSIE ======

#### AX25 setup

The N7NIX branch of the Dantracker works best when ax25 is used.

This is a link to a very good ax25 installation instruction for the Raspberry PI.: <u>http://k4gbb.no-ip.org/docs/Raspberry.html</u>

Follow those instructions, change the axports and ax25d.conf files with your own data, as well as the IFUPD file, and you're good to go on ax25.

Execute the following commands: (they make take a looooong time to finish)

- wget http://k4gbb.no-ip.org/docs/scripts/Instax25.new
- sudo chmod +x Instax25.new
- 🔸 🛛 sudo ./Instax25.new

Now adapt the settings for your own applications, following the next guidelines:

#### **AXPORTS**

Let's start with the axports file. This is the base for the configuration of all of the ax.25 devices. Edit the axports file located in /etc/ax25/ with the command

sudo nano /etc/ax25/axports

Here is an example:

```
# /etc/ax25/axports
# please change the NOCAL INTO TOUR OWN CALL SIGN
# The format of this file is:
#
# name callsign speed paclen window description
#
0 NOCAL-13 1200 255 7 144.800 MHz (1200 bps)
1 NOCAL-15 38400 255 7 TNOS/Linux (38400 bps)
```

#### Note:

- Use Numbers for Port names. You can give them names like radio or UHF1. That means more key strokes when you need to specify a Port name.
- The Call-ssid does not have a valid HAM Call. The ssid should be in the range of 0 15. This is a default and OK for ports that will never send over a radio link.
- The PacLen and the Window or MaxFrame values are set at max. All of these values are Defaults, including the baud rate, and are usually modified by the using Applications.
- DO NOT leave any Blank Lines !!!

#### AX25D.CONF

Create or edit /etc/ax25/ax25d.conf using the command sudo nano /etc/ax25/ax25d.conf It should look something like this.

```
# /etc/ax25/ax25d.conf
[N0CAL-14 via 0 ]
NOCALL * * * * * * L
default * * * * * * - rmsgw /usr/local/bin/rmsgw rmsgw -P 0 %U
# End /etc/ax25/ax25d.conf
```

#### **Create a port**

Connect your TNC to the Raspberry PI and check what device it is given. I hooked up a TNC-X with USB and it showed me /dev/ttyUSB0.

If you have various usb devices attached, sucg=h as a gps, keybard etc, do the following: Execute Isusb

root@dantracker:/home/pi# lsusb Bus 001 Device 007: ID 0461:0010 Primax Electronics, Ltd HP Keyboard Bus 001 Device 006: ID 0403:6001 Future Technology Devices International, Ltd FT232 USB-Serial (UART) IC Bus 001 Device 005: ID 10c4:ea60 Cygnal Integrated Products, Inc. CP210x UART Bridge / myAVR mySmartUSB light Bus 001 Device 004: ID 148f:5370 Ralink Technology, Corp. RT5370 Wireless Adapter Bus 001 Device 003: ID 0424:ec00 Standard Microsystems Corp. SMSC9512/9514 Fast Ethernet Adapter Bus 001 Device 002: ID 0424:9514 Standard Microsystems Corp. Bus 001 Device 001: ID 1d6b:0002 Linux Foundation 2.0 root hub

**Bus 001 Device 006** is my TNC-X. Remove the connection, check again and if it disappeared, then you know it for sure.

Next execute dmesg |grep USB Serial to find what devices are created:

root@dantracker:/home/pi# dmesg|grep 'ttyUSB'

[ 9.073821] usb 1-1.3: cp210x converter now attached to ttyUSB0

[ 9.086930] usb 1-1.4: FTDI USB Serial Device converter now attached to ttyUSB1

The cp201x is my GPS mouse and the TNC is attached to ttyUSB1 which uses the FTDI chip

#### Now execute:

/usr/local/sbin/kissattach /dev/ttyUSB0 0 44.128.1.10

#### My result:

# /usr/local/sbin/kissattach /dev/ttyUSB1 0 44.128.1.10
AX.25 port 0 bound to device ax0

Software requires EACH ax25 device to have a unique ip address. Do not use the address of your server or the loop back address (127.0.0.1). It is safe to use Amprnet addresses in the range of 44.128.100.0 to 44.128.0.0.

If it does not not return an error message, then the next step is to set the kiss parameters: /usr/local/sbin/kissparms -p 0 -r 128 -s 10 -t 250

Where :

-p is the Port name from axports,-r is the Persistence value,-t is the TxDelay

#### **Testing Ax Ports**

Stop a minute and test your device!

Be Sure that your TNC is in the KISS mode. NOTE: The ax25-tools package from my source still uses the old file names for call and listen. They are the same as axcall and axlisten.

#### Calibrate

Use the adapted version by K4GBB for the Raspberry PI You can use it to see if you have control of the TNC's PTT.

Download calibrate\_pi and place it in /usr/local/sbin/.

- wget http://k4gbb.no-ip.info/docs/rpi/calibrate\_pi
- cp calibrate\_pi /usr/local/sbin/calibrate\_pi

Use the portname from the axports file.

🔸 calibrate 0

This will send a full frame (256 chars) of alternating 1s & 0s to port 0.

Press Return to stop the test. The PTT will stay active until the TNC's transmit buffer is emptied.

If you get a error message about frame length being too long - check your axports file. The value for PacLen must be 256 and MaxFrames 7.

#### Listen

Use (ax)listen to check the receiver monitoring process.

listen -cart

The screen will go blank and print received frames as the are decoded by the TNC. Use Ctl-C to close the listen screen.

#### Call

The (ax)call command can be used to check the port's ability to connect and pass data. Call is a simple Term program.

The syntax is call <port> <call>v<path>

call 0 pa0esh-1 v pa0esh-2 (use your own call – it's just for testing)

#### NODE JS & NPM INSTALLATION

**Install node.js** (npm will be installed at the same time for that matter)

Note: As described at the beginning of this article, this fsection related to the installation of Node.js requires a Pi system based on the newer ARMv7 or ARMv8 chip such as the Pi 2 or Pi 3. NodeSource provides Node.js binaries for these newer ARMv7+ architectures, but not for Raspberry Pi systems based on the older ARMv6 architecture such as the Raspberry Pi Model B/B+ or the Raspberry Pi Zero.

Read the writing carefully on your Raspberry Pi circuit board to confirm is says something like "Raspberry Pi 3 Model B" or "Raspberry Pi 2 Model B". If in doubt, run the following command in the terminal:

#### 4 uname -m

If the result returned starts with "armv6", you are running a Raspberry Pi based on the older ARMv6 chipset and the next Node.js installation step will not work; otherwise, you are ready for the next step.

- curl -sL https://deb.nodesource.com/setup\_8.x | sudo -E bash -
- sudo apt-get install -y nodejs
- sudo ldconfig
- d .. (back to the dantracker directory)
- Now test the version with node -v & npm -v

My results (September 2017): v8.4.0

5.3.0

#### **INSTALL JSON-C.**

- git clone https://github.com/json-c/json-c.git
- \star cd json-c
- 🚽 autoconf -i
- 🔸 🛛 sh autogen.sh
- 4 ./configure
- 🔸 🛛 make && make install
- 🔸 🛛 sudo ldconfig
- d .. (back to the dantracker directory)

#### DOWNLOAD JQUERY

Check their website for the latest version - <u>http://jquery.com/</u> At this date (September 2017), the latest version was jquery-3.2.2

- npm install jquery
- d jquery && npm run build

Since it is the latest revision of this jquery, you may have to adapt the html files in /usr/share/dantracker. See their website for more information.

Now install the following nodes for npm:

- 🚽 🛛 sudo npm install -g node-gyp
- sudo npm install -g socket.io
- 🔸 🔰 sudo npm install -g ctype
- sudo npm install -g iniparser
- sudo npm install -g websocket
- sudo npm install -g connect

Whenever you get the following warnings, they are just that, warnings, and the installation should pose no problem...

npm WARN package.json github-url-from-git@1.1.1 No repository field. npm WARN package.json assert-plus@0.1.2 No repository field. npm WARN package.json ctype@0.5.2 No repository field.

Change back into the dantracker directory.

📥 cd..

touch .revision # creates the .revision file required for make....

Compile the core programs of the Dantracker

 make

if you get the following error:

# aprs-ax25.c:24:33: fatal error: netax25/kernel\_ax25.h: No such file or directory compilation terminated. make: \*\*\* [aprs-ax25.o] Error 1

then change the aprs-ax25 file as follows + -> #include <netax25/kernel\_ax25.h> becomes #include <netax25/ax25.h>

and do again:

- 🔸 make
- 🔸 sudo ./install.sh
- cp \*.js /usr/share/dantracker/

Now you copy the jquery file as well. Basil's install script does copy the file also, but I am not sure if he renames the file during copying – *to be investigated*....

adapt both /usr/share/dantracker tracker.html as well as spy.html for the correct library

```
</div>
<script src="jquery-1.9.1.min.js"></script>
<script src="spy-frontend.js"></script>
</body>
</html>
```

Edit config files /etc/tracker/aprs\_tracker.ini & /etc/tracker/aprs\_spy.ini change [station] mycall, put your range in, adapt the tier2 server name (**euro** for Europe and **noam** for North America etc...

Install iceweasel as a web socket compatible browser (Firefox branch) for local viewing if you view it on the Raspberry screen, other while use another pc on your local network and use the ip address of your Raspberry (http://ip-of-raspberry:8080/tracker.html

Pre testing: Reboot the Raspberry, login as root and change into the dantracker directory Then execute aprs

If you see something like the following you're ok on step one.

root@aprs:/home/pi/dantracker# aprs APRS v0.02.0429 () DEBUG: Calling iniparser for station call PA0ESH, ssid:0 Debug: aprsis filter string: r/52.259/6.755/100.0 Processed single key: Using dantracker v0.02.0429 (), key: ver, remaining: 0 Final str: Using dantracker v0.02.0429 () Processed single key: Software v0.02.0429 (), key: ver, remaining: 0 Final str: Software v0.02.0429 () Processed 2 lines, total keys: 2

Now we start the dantracker by executing /etc/tracker/tracker-up

You should see the following:

root@aprs:/home/pi/dantracker# /etc/tracker/tracker-up Starting Tracker Starting Spy There are screens on: 2279.Spy (30/06/13 11:01:13) (Detached) 2275.Tracker (30/06/13 11:01:13) (Detached) 2 Sockets in /var/run/screen/S-root.

#### finished starting tracker

Now check the status of the tracker by executing screen -r Tracker

Noted - you may have to carry out the following change to the tracker-up file...

On a raspberry it seems there is a problem with the creation of a log file.

Therefore modify the /etc/tracker/tracker-up file as follows #!/bin/sh echo "Starting Tracker" touch /tmp/aprs\_tracker.log # added in case of error screen -dmS Tracker -c /etc/tracker/.screenrc.trk echo "Starting Spy" screen -dmS Spy -c /etc/tracker/.screenrc.spy screen -ls echo "finished starting tracker"

Restart the Raspberry PI again and continue...

If you see verbose messages like these, your ok.

DEBUG: aprsax25\_connect(): Port 0 is using device ax0, callsign PA0ESH-7 PA0ESH-12 DEBUG: aprsax25\_connect(): Connected to AX.25 stack on rx socket 4, tx socket 5 DEBUG: tnc type is AX25 try aprsax25\_connect to APRS via WIDE1-1, socket=4 Waiting for node script to create a Unix socket UI Socket /tmp/N7NIX\_UI, connected with sock 7 .30.06.13 11:01:20: handle encap third party parse ok: call 0x1c01270, dest (nil), dest call 0x1c01900, time (nil), type 0x1c01870, pkt 0x1c013c8 Processed thirdparty: PI1NYV-C->APJI23 @1101: type: 0 PI1NYV-C>APJI23,TCPIP,PI1TWE-2\*:!5222.69ND00628.48Ea NIJVERDAL JO32FJ 30.06.13 11:01:21: beacon reason: ATREST, req: 1200 delta: 1372582881

Leave this screen by Ctrl-a-d.

Now with the Acces Point software, you have given the wlan0 device an IP address of 192.168.42.1. So when in the car with no Ethernet connection, point your iPhone, iPad of Android to this address after having made a Wi-Fi connection. At home use the ip address from the eth0 interface.

Find them both by executing ifconfig.....

pi@aprs ~/dantracker \$ ifconfig

eth0 Link encap:Ethernet HWaddr b8:27:eb:09:a3:c8 inet addr:10.0.1.14 Bcast:10.0.1.255 Mask:255.255.255.0 UP BROADCAST RUNNING MULTICAST MTU:1500 Metric:1 RX packets:119290 errors:0 dropped:0 overruns:0 frame:0 TX packets:56030 errors:0 dropped:0 overruns:0 carrier:0 collisions:0 txqueuelen:1000 RX bytes:79009703 (75.3 MiB) TX bytes:9305670 (8.8 MiB)

 Link encap:Local Loopback inet addr:127.0.0.1 Mask:255.0.0.0 UP LOOPBACK RUNNING MTU:16436 Metric:1 RX packets:0 errors:0 dropped:0 overruns:0 frame:0 TX packets:0 errors:0 dropped:0 overruns:0 carrier:0 collisions:0 txqueuelen:0 RX bytes:0 (0.0 B) TX bytes:0 (0.0 B)

 wlan0 Link encap:Ethernet HWaddr 00:0f:54:02:28:da
 inet addr:192.168.42.1 Bcast:192.168.42.255 Mask:255.255.255.0
 UP BROADCAST RUNNING MULTICAST MTU:1500 Metric:1 RX packets:10613 errors:0 dropped:44 overruns:0 frame:0 TX packets:9171 errors:0 dropped:0 overruns:0 carrier:0

collisions:0 txqueuelen:1000 RX bytes:1483359 (1.4 MiB) TX bytes:2680349 (2.5 MiB)

pi@aprs ~/dantracker \$

Note:

The install script does not setup apps to start on a power up or reboot. To have the spy & tracker apps startup at boot time do the following.

As root copy tracker startup script to the init.d dir then use udpate-rc.d to add the daemon.

🔸 su

cp tracker /etc/init.d/

On a Raspberry the script header had to be adapted because the requirement for ax25 to be started did not fit ell. Quick fix:

Edit the file as follows

# Required-Start:	<pre>\$remote_fs \$syslog</pre>
# Required-Stop:	<pre>\$remote_fs \$syslog</pre>

Save and exit

Also the heartbeat is not avalible so comment it out # echo "heartbeat" > /sys/class/leds/tiger\:green\:health/trigger

Add a daemon with sequence of 95

update-rc.d tracker defaults 95

The daemon script supports start, stop, restart & status

For example as root:

/etc/init.d/tracker status

To start & stop de Dantracker – N7NIX branch, use /etc/tracker/tracker-up (and down for that matter)

Make sure you have adapted the aprs\_tracker.ini file (and the aprs\_spy.ini file as well) and use ax25 to have all functions working.

For testing you can use NET, but the message fuctions will not work.

One handy feature I have done is to have the GPS connected, but use NET.

When I am driving in the car, the IPhone is setup as an Wi-Fi hotspot and connects to the Raspberry.

The range is set for the range of my VHF rigs with repeaters, approx. 60 km

Here is a screen picture of Sunday 26<sup>th</sup> of may 2013, after about 20 minutes of operation. In that mode.

PA0ESH 0.0km SW via TCPIP Xastir on iMac / when PC is on-line			
1:PA3AZN-2 43 sec 2:PD4U-3 56km W 3:PI1DEV 41km W 4:DB0TVA 58km SW	5:DB0EEO 57km SW 6:145.662- 59km SW 7:PI1SGM-2 2m57s 8:PI1ZWL-11 53km N		
Stationary, Alt 5 m 52.25860N 6.75795E 06:22:29 Locked: 8 sa PA0ESH-7 : Every 20 min	ats	ll.	
PA3DZX-13       9.7km E (12m18s ago)         Wind N 5/9m/s 10C 90%         Twente (bron: BuienRader.NL http://www.buienradar.nl)			
Messages EL-DB0BOH->EL-DB0BOH@1248:UNIT.RX Erlang,TX Erlang,count/10m,count /10m,none1,none2,logic EL-DM0ZPK->EL-DM0ZPK@1250:UNIT.RX Erlang,TX Erlang,RXcount/10m,TXcount /10m,none1,STxxxxx,logic			
ACK message  From callsign:	PA0ESH-7 To callsign	n:	
Enter message: Unable to communicate with the WebSocket server.			
TotalMessagesWeather10521	Encap Pkts 0	Error 48	
Shutdown Reset Confirm:			
Debug window 12:43: URL: 10.0.1.5 Port num: 8080 12:43: Callsign: CF_CALL value: PA0ESH-7 myName: PA0ESH-7			

### This is the part for the original dantracker again...

Change back into the dantracker directory

- 🔸 cd ..
- stouch .revision

Needed . You may have to add it later to the start script as well, as it did not stay on my Raspberry after a reboot, when I tried to ececute make again Note – this may be necessary for the N7NIX branch as well.

Now execute the compilation

📥 make

Do the same for the images (not required for N7NIX branch)

- d images
- 🔸 make

cd ..

This is all, and if you had no errors, then the test will show that it works.

#### Now the test

First check for the gps sudo ./detect\_gps.py

In my case, I have a unknown GPS mouse and a TNC-X with FTDI USB to serial port The output shows up as:

#### pi@raspberrypi ~/dantracker-ori \$ sudo ./detect\_gps.py Irwxrwxrwx 1 root root 12 Apr 23 19:40 /dev/gps -> /dev/ttyUSB1 Irwxrwxrwx 1 root root 12 Apr 23 19:40 /dev/radio -> /dev/ttyUSB0

Copy the aprstest.ini file from the samples directory into your aprs directory and rename the call to your own call and change the position to some where near your home. This will deliver a lot of data for the stress test

Now, run a screen session for the aprs function as follows screen -dmS aprs ./aprs –m /home/pi/dantracker/aprs.ini

The aprs job is now up and running on your raspberry in a (hidden) screen.

That's it. On my screen is looks as in the youtube movie. Now adapt the aprs.ini file from the samples directory to your real situation. The have fun with the dantracker, like I had. In case you wish to autostart the whole thing do as follows:

Create a startup file in the directory /etc/init.d, called dantracker.

nano /etc/init.d/dantracker

Write the following into the file:

#! /bin/sh # /etc/init.d/noip

### BEGIN INIT INFO
# Provides: dantracker
# Required-Start: \$remote\_fs \$syslog
# Required-Stop: \$remote\_fs \$syslog
# Default-Start: 2 3 4 5
# Default-Stop: 0 1 6
# Short-Description: Simple script to start the original dantracker at boot
# Description: A simple script by pa0esh to start the original dantracker programs at boot in
two screens. PA0ESH @21 April 2013
### END INIT INFO

# If you want a command to always run, put it here

```
# Carry out specific functions when asked to by the system
case "$1" in
 start)
  echo "Starting the Dantracker"
  # run application you want to start and change the working dir according to your system
  cd /home/pi/dantracker-ori
  screen -dmS aprs ./aprs -m
  screen -dmS ui xinit /home/pi/dantracker-ori/ui
  ;;
 stop)
  echo "Stopping the Dantracker"
  # kill application you want to stop
  killall screen
  killall ui
  ;;
 *)
  echo "Usage: /etc/init.d/dantracker {start|stop}"
  exit 1
  ;;
esac
exit 0
```

sudo chmod 755 /etc/init.d/dantracker

To register your script to be run at start-up and shutdown, run the following command: sudo update-rc.d dantracker defaults

If you ever want to remove the script from start-up, run the following command:

sudo update-rc.d -f dantracker remove

73's Erik, PA0ESH

# Notes....

Somewhere in the file aprs-is.c I found data pertaining to the login for Dan I have changed that to my own data, and you should do so as well.

This is the part you are looking for.....

After modifying execute make command...

If you use an additional Wi-Fi adapter, like I did, you may have to change your ip tables and flush them..

### How to: Linux flush or remove all iptables rules

Here is small script that does this. Debian or Ubuntu GNU/Linux does not comes with any SYS V init script (located in /etc/init.d directory).

You create a script as follows and use it to stop or flush the iptables rules.

Please don't type rules at command prompt. Use the script to speed up work.

Procedure for Debian / Ubuntu Linux

A) Create /root/fw.stop /etc/init.d/fw.stop script using a texteditor (nano)

```
#!/bin/sh
echo "Stopping firewall and allowing everyone..."
iptables -F
iptables -X
iptables -t nat -F
iptables -t nat -F
iptables -t mangle -F
iptables -t mangle -F
iptables -t mangle -X
iptables -P INPUT ACCEPT
```

# iptables -P FORWARD ACCEPT iptables -P OUTPUT ACCEPT

Make sure you can execute the script: # chmod +x /root/fw.stop

You can run the script: #/root/fw.stop

#### **ORIGINAL README FILE FOR DANTRACKER – N7NIX**

Pre-installation requirements

Dependencies:

libfap:

http://pakettiradio.net/libfap/ wget http://pakettiradio.net/downloads/libfap/1.3/libfap-1.3.tar.gz tar -zxvf libfap-1.3.tar.gz

cd libfap-1.3 # apply fap patch patch -p2 < ./<path\_to\_tracker\_src>/fap\_patch.n7nix sudo cp src/fap.h /usr/local/include/ ./configure make sudo make install NOTE: libraries install to /usr/local/lib

libiniparser: http://ndevilla.free.fr/iniparser/ wget http://ndevilla.free.fr/iniparser/iniparser-3.1.tar.gz tar -zxvf iniparser-3.1.tar.gz

cd iniparser sudo cp src/iniparser.h /usr/local/include sudo cp src/dictionary.h /usr/local/include make sudo cp libiniparser.\* /usr/local/lib

GTKAPP: Only used by gtk app, see Makefile gtk+-2.0 libgtk2.0-dev

AX25: Only used with AX25 stack Build from source http://www.linux-ax25.org/wiki/CVS libax25-dev

WEBAPP: Only used by web app, see Makefile node.js requires openssl libssl-dev https://github.com/joyent/node git clone git://github.com/ry/node.git

cd node ./configure make sudo make install verify by running: \$ node -v && npm -v

json-c https://github.com/json-c/json-c git clone git://github.com/json-c/json-c.git

cd json-c sh autogen.sh ./configure make sudo make install Idconfig javascript libraries Needs version 1.8.3 or greater wget http://bit.ly/jqsource -O jquery.js sudo cp jquery.js /usr/share/dantracker Above taken care of by install script. node modules ctype iniparser websocket connect Tools required: build-essential (includes libc-dev, make, gcc, ... etc) pkg-config imagemagick git automake autoconf libtool **Basic Installation** -----`cd' to the directory containing the source code and type `make' to compile, link & create png image files. fap Installation \_\_\_\_\_ Before building the fap library run the fap patch in the tracker repository against its source tree. You need to supply the directory path to dantracker source. cd libfap-1.3 patch -p2 < ./<path to tracker src>/fap patch.n7nix

For dantracker n7nix ONLY

Web app install notes

Once core apps, aprs for tracker & aprs-ax25 for spy are built need to do the following:

check that this package is installed: screen

Install node.js & npm (package manager for node) Install node.js modules globally: npm -g install <module name> npm list -g

ctype iniparser websocket connect

As root run install.sh found in tracker dir. This will copy binary, javascript & config files to appropriate directories.

Confirm javascript library jquery-1.8.3.min.js exists here: /usr/share/dantracker/

Edit config files /etc/tracker/aprs\_tracker.ini & /etc/tracker/aprs\_spy.ini

change [station] mycall

If you don't have a gps connected change [gps] type from nmea to static If gps is connected set serial port and set type to nmea

For AX.25 operation change config for [ax25] port = xxx This should be the same port name used in /etc/ax25/axports

As root run /etc/tracker/tracker-up

As root run screen -ls

should see something similar to:

There are screens on: 30680.Tracker (04/15/2013 06:10:32 PM) (Detached) 21348.Spy (04/15/2013 01:00:42 PM) (Detached) 2 Sockets in /var/run/screen/S-root.

Attach to a screen terminal

screen -r Spy

or

screen -r Tracker

If you are successful in getting these screen sessions running & you are attached use these 'screen' commands:

list windows: ctrl a w

change windows ctrl a 0 ctrl a 1 ctrl a 2

leave session by detaching: ctrl a d

kill them: ctrl a \

Open up your browser Is your browser web socket enabled? http://caniuse.com/websockets

web url for tracker

<your\_machine\_name>:8080/tracker.html or localhost:8080/tracker.html

web url for spy

<your\_machine\_name>:8081/spy.html or localhost:8081/spy.html

The install script does not setup apps to start on a power up or reboot. To have the spy & tracker apps startup at boot time do the following. As root copy tracker startup script to the init.d dir then use udpate-rc.d to add the daemon.

su cd /etc/tracker cp tracker /etc/init.d/

Add a daemon with sequence of 95

update-rc.d tracker defaults 95

The daemon script supports start, stop, restart & status For example as root:

/etc/init.d/tracker status

Starting tracker or spy from command line without using script

Make sure tracker or spy is not already running

\_\_\_\_\_

screen -ls

screen -S Tracker -c /etc/tracker/.screenrc.trk

or

screen -S Spy -c /etc/tracker/.screenrc.spy

Console Programs

Stand alone programs displaying to console only.

./aprs-is

./aprs-is -c <path to ini config file>/aprs.ini

Display packets from an APRS server. Need to specify in ini file: [net] server\_host\_address, server\_port and range [static] lat and long [gps] type=static

./aprs-ax25

\_\_\_\_\_

./aprs-ax25 -c <path\_to\_ini\_config\_file>/aprs.ini

Display packets from AX.25 stack Need to edit compile time define aprs-ax25.c and remove #define PKT\_SOCK\_ENABLE.

./fakegps

-----

Continuously display gps GGA & RMC sentences that will be used if [gps]:type=static is configured.

./faptest < file\_containing\_aprs\_packet

-----

Reads a packet from stdin and passes to fap library.

For dantracker kk7ds ONLY

as aprs executable and rename to aprs.ini

Running dantracker kk7dds edition

Stress-test by using examples/aprstest.ini (modified as appropriate), which will attempt to eat the entire APRS-IS world feed without crashing.

**Test Programs** 

-----

Test stand alone programs displaying to console.

./aprs-is ./aprs-ax25

Test display interface.

Using socket connect with AF\_INET ./ui -i with ./uiclient -i [NAME] [VALUE]

Using socket connect wit AF\_UNIX ./ui -w with ./uiclient -w [NAME] [VALUE]

Normal operation

UI socket connect via AF\_INET ./ui -i with ./aprs -d 127.0.0.1

UI socket connect via AF\_UNIX ./ui -w with ./aprs

#### **TNC-X Raspberry & FTDI issues**

### TNC-X

I like theTNC-X with the USB option, but the FTDI driver (ftdi\_sio) does not seem to work correctly on the ARMHF OS. Download the <u>AN\_220\_FTDI\_Drivers\_Installation\_Guide\_for\_Linux</u> from the FTDI website and follow the instructions in the PDF.

Simplifed instructions Change directories to /usr/local/src/ cd /usr/local/src/ Download the driver tarball wget http://www.ftdichip.com/Drivers/D2XX/Linux/libftd2xx1.1.12.tar.gz Unpack the archive, creating the following directory structure: build arm926 i386 x86 64 examples libusb ftd2xx.h WinTypes.h tar xfvz libftd2xx1.1.12.tar.gz Change to the arm926 directory cd build/arm926 If you're already root, then not necessary. sudo su Copy the libraries to /usr/local/lib. cp lib\* /usr/local/lib Change permissions. chmod 0755 /usr/local/lib/libftd2xx.so.1.1.12 Create a symbolic link to the 1.1.12 version of the shared object. In -sf /usr/local/lib/libftd2xx.so.1.1.12 /usr/local/lib/libftd2xx.so